

AESTHETIC FEET KIT LC0158

Warnings

- ⚠ This instruction is an integral part of the booklet of the appliance on which the kit is installed. Please consult this booklet for general warnings and fundamental safety rules.
- ⚠ For a rapid and right assembly of the components follow carefully the sequences described in the various sections.
- ⚠ All the operations must be performed by qualified personnel using the required Personal Protective Equipment.
- ⚠ It is necessary, for right functioning of the device, that during the whole installation phase the working space remains clean.

Description

The aesthetic foot kit covers the hydraulic connection pipes coming from the floor.

LC0158 - Feet for covering floor pipes, h=80 mm

- ⚠ The aesthetic feet should not be used to anchor the appliance on the floor.

- ⚠ To anchor the appliance on the floor, use the dedicated LC0606 floor-fixing feet.

Combinable products

The LC0158 accessory can be installed for all sizes of >OSMO< SL / RS.

Mounting

To fix the aesthetic feet kit:

- ▶ rest the back of the appliance on a horizontal surface
- ▶ screw the 4 threaded supports to the structure (supplied)
- ▶ return the appliance in a vertical position
- ▶ fix the appliance to the wall
- ▶ fix the two aesthetic covers to the supports

1. Threaded supports
2. Covering feet

